

Steps AO4 Final Impression

1. Insert the (4-6) segment onto the abutment as numbered. Make sure they are not touching before you hand tighten.
2. Mix pattern resin and load into a monoject syringe with the tip cut. Or use a light cure flowable material. Connect the segments together making sure that the resin does not touch the tissue.
3. Try in the custom or stock tray. Cut openings or verify openings will allow impression pins to be exposed.
4. Paint the tray and use rope wax or bee's wax to cover the holes.
5. Inject PVS impression material under pattern resin jig and load tray. Make final impression ensuring that pins are exposed.
6. Once set, unscrew the pins making sure they are loose and retrieve impression.

